




Canon PowerShot SX600 HS Flash Assembly Replacement

This guide will show you how to replace the camera's flash assembly.

Written By: Scott Childress



INTRODUCTION

By fixing your flash, you can once again take bright, vibrant photographs.



TOOLS:


- [Phillips #000 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [ESD Safe Tweezers Blunt Nose](#) (1)
-

Step 1 — Battery




- To remove the battery, locate the battery cover on the bottom of the camera.
- Using your thumb, press down on the cover and slide it outwards.

Step 2



- Depress the orange lever holding the battery in place to unlock it.

Step 3



- Use your fingers to remove the battery.
- ☑ Be sure to remember the alignment of the nodes for reassembly.

Step 4 — Power and Shutter Buttons



- Use a #000 Phillips screwdriver to unscrew the four 4mm screws located on the sides of the camera (2 for each side).

Step 5




- Unscrew the four 2mm located on the bottom of the camera using a Phillips #000 screwdriver.

Step 6



- Use a plastic opening tool to loosen and remove both the front and back plates of the camera, as well as the two side pieces.

Step 7





- Unscrew the three 2mm screws attaching the piece to the camera frame with a #000 Phillips screwdriver.

Step 8




- Use an opening tool to gently remove the power and shutter button assembly from the frame.

Step 9 — Display Screen




- Unscrew the 2mm screw connections of the main board protector from the camera frame using a #000 Phillips head screwdriver (2 on front, 1 on top)

Step 10



- Use a Phillips #000 screwdriver to unscrew the 4mm screw.

Step 11




- Use a pair of tweezers to remove the no-fuss connector from its holder.

Step 12




- Gently lift the protector from the frame.

Step 13




- Lift the LCD screen ZIF connector tab and remove the ribbon cable.
- Detach the no-fuss connector.
- Lift the screen from its holder.

Step 14 — Flash Assembly




- Unplug the assembly from the main no-fuss connector.

Step 15




- Unplug the assembly from its flat-top connection.

Step 16



- Use a #000 Phillips screwdriver to remove the three 4mm screws that hold the assembly to the frame.

Step 17



- Gently lift the assembly out of its place.

Fix your Canon's flash in order to take bright, vibrant photographs.

This document was last generated on 2017-06-29 05:22:04 AM.